


Agitator
 Models U3101, U3103, U3105, U3105-035, U3105-930, U3107, U3109, U3109-100, U3223-9,
 U3225, U3305, U3305-030, U3307, U3311, U4201, U4203, U4205, U4209, U421



Agitator
 Models U3101, U3103, U3105, U3105-035, U3105-930, U3107, U3109, U3109-100, U3223-9,
 U3225, U3305, U3305-030, U3307, U3311, U4201, U4203, U4205, U4209, U421

	48416009	Agitator Assem. Comp.
1	41435021	Thread Guard
2	43267002	Agitator Bearing Assem. (2)
3	21347003	Thrust Washer (2)
4	38537002	Agitator End Pulley
5	48445019	Agitator Brush (4)
6		Not Available
7	38528008	Agitator Belt
8	160070	Agitator Shaft
9	36422001	Agitator End
	41435023	Agitator End Assem. (Incl. It. 2 & 3)
10	41435018	Thread Guard