


Models: EC-14TWT6, EC-14TAT6, EC-12TWT6,
EC-12TWT4, EC-12TWT2, EC-12TXT2, EC-12SXT4B, EC-T4840



Models: EC-14TWT6, EC-14TAT6, EC-12TWT6,
EC-12TWT4, EC-12TWT2, EC-12TXT2, EC-12SXT4B, EC-T4840

■ ELECTRICAL PARTS

1-1 S-555 Motor Assy
1-1 S-554 Motor Assy, 12SXT4B
1-1 S-895 Motor Assy, 14TWT6, 14TAT6,
12TWT6
1-1 S-906 Motor Assy, T4840
1-2 S-553 Carbon Brush
1-2 S-552 Carbon Brush, 12SXT4B
1-2 S-912 Carbon Brush, 14TWT6, 14TAT6,
12TWT6
1-3 S-837 Power Cord, 12TWT2
1-3 S-838 Power Cord, 12TXT2, 12SXT4B
1-3 S-839 Power Cord, 12TWT6, 12TWT4
1-3 S-905 Power Cord, 14TWT6, 14TAT6
1-3 S-074 Power Cord, T4840
1-4 S-206 Motor Lead Wires
1-5 S-207 Circuit Lead Wires, 14TWT6,
14TAT6, 12TWT6
1-6 S-208 Lamp Lead Wires
1-7 S-095 Power Control Assy, 14TWT6,
14TAT6, 12TWT6
1-8 S-805 Triac Assy, 14TWT6, 14TAT6,
12TWT6
1-9 S-549 On/Off Switch
1-9 S-907 On/Off Switch, 14TWT6, 14TAT6,
14TWT6, 12TWT4
1-9 S-030 On/Off Switch, T4840
1-10 ... S-840 Lamp
1-10 ... S-209 Lamp, T4840
1-11 ... S-556 Lamp Socket
1-11 ... S-947 Lamp Socket, T4840
1-12 ... S-557 Fuse
1-13 ... S-558 Fuse Holder
1-13 ... S-927 Fuse Holder, T4840

■ MECHANICAL PARTS

2-1 S-101 Dust Indicator Assy
2-2 S-559 Dust Indicator Base, 14TWT6,
14TAT6, 12TWT6
2-3 S-560 Meter Pipe Connector, 14TWT6,
14TAT6, 12TWT6
2-4 S-561 Handle Mounting Base
2-5 S-702 Belt, flat
2-6 S-154 Body Seal Tape S
2-7 S-155 Body Seal Tape L
2-8 S-213 Spring, cord hanger
2-9 S-563 Indicating Plate, 14TWT6, 14TAT6,
12TWT6
2-10 ... S-564 Panel Seal
2-10 ... S-597 Panel Seal, T4840
2-11 ... S-565 Body Seal
2-12 ... S-566 Seal, motor cover
2-13 ... S-245 Motor Shelter Plate, 12SXT4B
2-14 ... S-568 Secondary Filter
2-14 ... S-567 Secondary Filter, 14TWT6, 14TAT6,
12TWT6, T4840
2-15 ... S-111 Clamp Spring
2-16 ... S-112 Vibration-Proof Rubber
2-16 ... S-569 Vibration-Proof Rubber, 12SXT4B
2-17 ... S-646 Vibration-Proof Fixing Rubber
2-18 ... S-570 Sound-Proof Sponge
2-19 ... S-115 Wheel Shaft
2-20 ... S-571 Leg Assembly TA
2-21 ... S-572 Leg Assembly TB
2-22 ... S-573 Clean Filter
2-23 ... S-574 Body Support
2-24 ... S-575 Belt Stopper
2-25 ... S-576 Reflection Plate
2-26 ... S-577 Lamp Support
2-27 ... S-217 Cord Bushing, nozzle head
2-28 ... S-578 Heat-Proof Plate
2-29 ... S-579 Head Pipe
2-30 ... S-124 Head Reinforcing Plate
2-31 ... S-125 Screw, bottom plate
2-32 ... S-580 Belt Change Lever Support
2-33 ... S-581 Belt Change Plate
2-34 ... S-128 Belt Change Shaft

2-35 ... S-582 Belt Change Spring
2-36 ... S-130 Pedal Support
2-37 ... S-131 Pedal Spring
2-38 ... S-132 Pedal Shaft
2-39 ... S-584 Brush Roll Assy
2-39 ... S-583 Brush Roll Assy, 14TWT6, 14TAT6
2-39 ... S-1247 ... Brush Roll Assy, T4840
2-40 ... S-133 Rotor Assy
2-40 ... S-585 Rotor Assy, 14TWT6, 14TAT6, T4840
2-41 ... S-747 Idling Pulley Assy, 14TWT6, 14TAT6
2-42 ... S-141 Shaft Assy
2-42 ... S-135 Shaft Assy, 14TWT6, 14TAT6
2-42 ... S-1025 ... Shaft Assy, T4840
2-43 ... S-142 Agitator Support A
2-43 ... S-587 Agitator Support A, 14TWT6, 14TAT6
T4840
2-44 ... S-143 Agitator Support B
2-44 ... S-588 Agitator Support B, 14TWT6, 14TAT6
T4840
2-45 ... S-120 Felt Stopper 3
2-46 ... S-139 Brush Rotor A, 14TWT6, 14TAT6,
T4840
2-47 ... S-590 Brush Rotor B
2-47 ... S-589 Brush Rotor B, 14TWT6, 14TAT6,
T4840
2-48 ... S-241 Main Body Packing
2-49 ... S-161 Main Body Packing M
2-50 ... S-148 Spring, bottom plate
2-51 ... S-149 Roller Shaft
2-52 ... S-150 Seal Tape A
2-53 ... S-151 Seal Tape B
2-54 ... S-152 Seal Tape C
2-55 ... S-121 Belt, vibration-proof rubber
2-56 ... S-246 M Packing
2-57 ... S-159 Seal Tape E
2-58 ... S-160 Seal Tape F
2-59 ... S-158 Seal Tape G
2-60 ... S-247 Seal Tape D
2-61 ... S-162 Belt Guide Plate
S-1245 ... U-Seal, T4840
S-247 ... Seal Tape D, T4840
S-1246 ... Seal Tape H, T4840
S-1248 ... P Spacer, T4840

■ EXTERNAL PARTS

3-1 S-591 Front Handle
3-2 S-592 Rear Handle
3-3 S-593 Upper Hanger
3-4 S-594 Hose Clamp
3-5 S-595 Pipe Clamp
3-6 S-596 Brush Clamp
3-7 S-564 Panel Seal
3-8 S-911 Main Body
3-8 S-598 Main Body, 12TWT2, 12TXT2,
12SXT4B
3-8 S-1249 ... Main Body, T4840
3-9 S-956 Panel, 14TWT6
3-9 S-841 Panel, 12TWT6
3-9 S-842 Panel, 14TAT6
3-9 S-843 Panel, 12TWT4
3-9 S-844 Panel, 12TWT2, 12TXT2
3-9 S-845 Panel, 12SXT4B
3-9 S-1250 ... Panel, T4840
3-10 ... S-604 Slide Knob
3-11 ... S-608 Dust Cover, 12SXT4B
3-11 ... S-846 Dust Cover, 14TWT6
3-11 ... S-847 Dust Cover, 12TWT6, 12TWT4
3-11 ... S-848 Dust Cover, 12TWT2, 12TXT2
3-11 ... S-849 Dust Cover, 14TAT6
3-11 ... S-1251 ... Dust Cover, T4840
3-12 ... S-850 Clamp Knob, 14TAT6
3-12 ... S-609 Clamp Knob, 14TWT6
3-12 ... S-610 Clamp Knob, 12TWT6, 12TWT4
3-12 ... S-611 Clamp Knob, 12SXT4B
3-12 ... S-851 Clamp Knob, 12TWT2, 12TXT2
3-12 ... S-1252 ... Clamp Knob, T4840
3-13 ... S-612 Hose Assembly

3-14 ... S-191 Head Shelter Plate
3-15 ... S-178 Wheel
3-16 ... S-852 Motor Cover, 14TAT6
3-16 ... S-613 Motor Cover, 14TWT6
3-16 ... S-615 Motor Cover, 12SXT4B
3-16 ... S-853 Motor Cover, 12TWT6, 12TWT4
3-16 ... S-855 Motor Cover, 12TWT2, 12TXT2
3-16 ... S-1253 ... Motor Cover, T4840
3-17 ... S-856 Nozzle Head L Assy, 14TAT6
3-17 ... S-857 Nozzle Head L Assy, 14TWT6
3-17 ... S-1254 ... Nozzle Head L Assy, T4840
3-17 ... S-0520 ... Nozzle Head M Assy, 12TWT6, TWT4
3-17 ... S-883 Nozzle Head M Assy, 12TWT2,
12TXT2
3-17 ... S-858 Nozzle Head M Assy, 12SXT4B
3-18 ... S-620 Lens L
3-18 ... S-621 Lens M
3-18 ... S-859 Lens M, 12SXT4B
3-18 ... S-860 Lens M, 12TXT2
3-19 ... S-658 Pedal L
3-20 ... S-624 Belt Change Lever
3-21 ... S-186 Belt Cover L, 14TWT6, 14TAT6, T4840
3-21 ... S-187 Belt Cover M
3-22 ... S-625 Bottom Plate L, 14TAT6, 14TAT6,
T4840
3-22 ... S-626 Bottom Plate M
3-23 ... S-188 Knob, bottom plate
3-24 ... S-189 Roller
3-25 ... S-190 Pulley Cover
2-26 ... S-627 Out Extension Pipe
3-27 ... S-628 In Extension Pipe
3-28 ... S-629 Crevice Tool
3-28 ... S-876 Crevice Tool, T4840
3-29 ... S-630 Nozzle Brush
3-30 ... S-861 Upholstery Nozzle
3-30 ... S-631 Upholstery Nozzle, T4840
3-31 ... S-632 Hole Cover
3-32 ... S-815 Plastic Wand, 14TWT6, 14TAT6,
12TWT6

■ MISCELLANEOUS

4-2 S-007 Paper Bag, 3 pack
4-3 S-862 Feature Sticker
4-3 S-864 Feature Sticker, 12TWT2, 12TXT2
4-3 S-865 Feature Sticker, 12SXT4B
4-3 S-882 Feature Sticker, T4840
4-4 S-866 Name Plate, 14TAT6
4-4 S-867 Name Plate, 12TXT2
4-4 S-868 Name Plate, 14TWT6
4-4 S-869 Name Plate, 12TWT6
4-4 S-870 Name Plate, 12TWT4
4-4 S-871 Name Plate, 12TWT2
4-4 S-872 Name Plate, 12SXT4B
4-4 S-1255 ... Name Plate, T4840

■ SCREWS, NUTS and WASHERS

5-1 S-639 Special Screw, handle fixing
5-2 S-233 Washer, upper hanger/clamp knob
5-3 S-197 Washer, wheel shaft
5-4 S-198 Wave Washer
5-5 S-199 Special Nut
5-6 S-200 Nut
5-7 S-201 Speed Nut
5-8 S-202 Screw
5-9 S-203 Screw
5-10 ... S-204 Screw
5-11 ... S-641 Screw
5-12 ... S-236 Screw
5-13 ... S-642 Screw
5-14 ... S-643 E-Crip
5-15 ... S-238 E-Crip
5-16 ... S-644 Screw
5-17 ... S-202 Screw